ORDER NO. HAD8610738C0
A6

Service Manual

Compact Disc Player

SL-P520

SL-P520

COMPACT disc DIGITAL AUDIO

DIGITAL

Compact Disc Player

Color

(K)...Black Type
(S)...Silver Type

Color	Areas
(K)	[M].....U.S.A.
(K)	[MC]...Canada.
(K) (S)	[E].....Switzerland and Scandinavia.
(K) (S)	[EK]....United Kingdom.
(K) (S)	[XL]....Australia.
(K) (S)	[EG]...F.R. Germany.
(K) (S)	[EB]....Belgium.
(K) (S)	[EH]...Holland.
(K) (S)	[EF]....France.
(K) (S)	[Ei].....Italy.
(K) (S)	[XA]....Asia, Latin America, Middle Near East, Africa and Oceania.
(K) (S)	[XB]....Saudi Arabia.
(K) (S)	[PA]....East PX.
(K) (S)	[PE]....European Miliary.
(K) (S)	[PC]....European Audio Club.

SPECIFICATIONS [*Measured by EIAJ(CP-307)]

■ Audio

No. of channels	2(left and right stereo)
Frequency response	4—20,000 Hz ±0.3 dB*
Dynamic range	96 dB*
S/N ratio	100 dB*
Harmonic distortion	0.0015% (1 kHz, 0 dB)*
Total harmonic distortion	0.003% (1 kHz, 0 dB)*
Channel separation	100 dB
Wow and flutter	Below measurable limit*
Low-pass filter	Hight Resolution Digital Filter
Output voltage	2.0 V (at 0 dB)*
Output impedance	Approx. 600Ω
Load impedance	More than 10 kΩ

■ Signal Format

Sampling frequency	44.1 kHz
Correction system	Technics Super Decoding Algorithm
D-A conversion	16-bit linear

■ Pickup

Type	Fine-focus, one beam
Access time	1 second* (access to the last track)
Light source	Semiconductor laser
Wavelength	780 nm
Traverse system	High-speed linear access system
Spindle system	Brushless DD motor

■ Infrared remote control unit

Dimensions (W×D×H)	65×155×18 mm
Batteries	UM-3 "AA" batteries or IEC R6 or equivalent (1.5 V×2)
Weight	140 g (including batteries)

■ Headphones

Output level	80 mW max. (variable)
Impedance	32 Ω
Plug	¼ inch stereo

■ General

Power supply	For U.S.A. and Canada: AC 120 V, 60 Hz For United Kingdom and Australia: AC 240 V, 50 Hz For Continental Europe: AC 220 V, 50 Hz For Others: AC 110~127 V/220~240 V, 50/60 Hz
Power consumption	17 W
Dimensions (W×D×H)	430×260×87 mm (16-15/16"×10-1/4"×3-13/32")
Weight	4.3 kg (9.5 lbs.)

Technics

Matsushita Services Company
50 Meadowland Parkway,
Secaucus, New Jersey 07094

Panasonic Hawaii Inc.
91-238 Kauhi St. Ewa Beach
P.O. Box 774
Honolulu, Hawaii 96808-0774

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

Panasonic Sales Company, Division of Matsushita Electric of Puerto Rico, Inc.
Ave. 65 De Infanteria, KM 9.7
Victoria Industrial Park
Carolina, Puerto Rico 00630

Matsushita Electric of Canada Limited
5770 Ambler Drive, Mississauga,
Ontario, L4W 2T3

Panasonic Tokyo Office
Matsushita Electric Trading Co., Ltd.
6th Floor, World Trade Center Bldg.,
No. 4-1, Hamamatsu-cho 2-Chome, Minato-ku,
Tokyo 105, Japan

■ Functions

Automatic play	•All tracks
Random access play	•Random access to any track or index
Program play	•Max. of 20 program selections
Skip play	•Forward and backward track skip
	•Forward and backward program track skip
Search play	•Forward and backward manual search
	•Dial search (2-speed)
Display functions	•Music Matrix (20 tracks)
	•Track number display
	•Index number display
	•Time display (min./sec.)
	•Overflow mark (≥)
	•Repeat indicator
	•A-B repeat indicator
	•Search speed indicator
	•Output level indicator
	•Auto space indicator
	•Time mode indicator
	When using remote control unit:
	•dB display
	•Output level indicator
	•Music scan indicator
	•Programmed order (No.) (when recall button is pressed)

■ Infrared remote control unit

Remote control function	Basic buttons: 7
	Program buttons: 12
	Time mode select buttons: 1
	Index button: 1
	Recall button: 1
	Music scan button: 1
	Repeat button: 1
	A-B repeat button: 1
	Digital volume attenuation buttons: 2

Specifications are subject to change without notice for further improvement.
Weight and dimensions are approximate.

■ CONTENTS

	Page
SAFETY PRECAUTION	2
PRECAUTION OF LASER DIODE	3
BEFORE USING THIS UNIT	3
LOCATION OF CONTROLS	4
PLAYING A DISC	6
HANDLING PRECAUTIONS FOR OPTICAL PICKUP	10
DISASSEMBLY INSTRUCTIONS	11
HOW TO REPLACE IC'S (Small outline type)	15
TERMINAL FUNCTION OF LSI	16
TROUBLESHOOTING	20
RESISTORS AND CAPACITORS	22
REPLACEMENT PARTS LIST	24
EXPLODED VIEWS	27
PRINTED CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM	30
PRINTED CIRCUIT BOARDS	32
SCHEMATIC DIAGRAM	36
BLOCK DIAGRAM	43
PACKING	46

■ SAFETY PRECAUTION (This "safety precaution" is applied only in U.S.A.)

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.

• INSULATION RESISTANCE TEST

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screwheads antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between 3MΩ and 5.2MΩ to all exposed parts. (Fig. A) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig. B)

Note: Some exposed parts may be isolated from the chassis by design. These will read infinity.



(Fig. A)
Resistance = 3MΩ—5.2MΩ



(Fig. B)
Resistance = Approx ∞

4. If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.

■ PRECAUTION OF LASER DIODE

Caution: This product utilizes a laser diode.
ADVARSEL: I dette a apparat anvendes laser.



Obs:
Apparaten innehåller laser
Komponent av höger laserklass
än klass 1.

- **Use of caution labels** Note: ○ Mark is used, × Mark is not used.

Areas	Disc clamper	SQWD33	SQWD11-1	SRNZ010S01	SRNZ010S02
[M], [PA], [PE], [PC]	○	×	×	×	×
[MC]	○	○	×	×	×
[E]	○	×	○	○	○
[EK], [XL], [EG] [EB], [EH], [EF] [Ei], [XB], [XA]	○	×	×	○	○


"CAUTION—HAZARDOUS LASER, AND ELECTROMAGNETIC RADIATION WHEN OPEN"
"ATTENTION—RAYONNEMENT LASER ET ELECTROMAGNETIQUE DANGEREUX SI OUVERT"
SQWD33
Disc clamper
DANGER-Invisible laser radiation when open.
AVOID DIRECT EXPOSURE TO BEAM.


ADVARSEL - Usynligt laserlys udstråles ved åbning. UNDGÅ DIREKTE BESTRÅLING. SQWD11-1
VAROITUS! Laite sisältää laserdiodin, joka lähettää näkymätöntä silmille vaarallista lasersäteilya

■ BEFORE USING THIS UNIT

1. Place a soft cloth under the unit to protect it from scratches.
2. Press the lock shaft on the bottom panel to the in (FREE) position (▙ → ▂).

NOTE:
IF THE PLAYER IS TRANSPORTED AGAIN, PERFORM THE FOLLOWING STEPS:
1) Remove the disc from the holder.
2) Press the lock shaft to the out (LOCK) position (▂ → ▙).
CAUTION:
Do not transport the player without locking the lock shaft.
SEVERE DAMAGE WILL RESULT.



■ LOCATION OF CONTROLS

• **Front panel**



• **Display panel**



TRACKING OFFSET ADJUSTMENT

1. Connect CH1 of the oscilloscope to the TJ301 (+) and TJ302 (−). Connect the CH2 to the TJ101 (+) and TJ302 (−) of the main P.C.B.
   Oscilloscope setting: VOLT 500mV (CH1)
   100mV (CH2)
   SWEEP.....0.5msec.
   INPUT.....AC (CH1)
   DC (CH2)
   MODE.....NORM
   (Triggering via CH1)
2. Turn the power switch "**ON**", and playback **track 9** (black band) of test disc (**SZZP1057C**).
3. Trigger so that waveforms appear on the oscilloscope, and adjust VR103 so that the depression of RF of CH1 Changes to a smooth envelope and that the waveform amplitude of CH2 is minimized or becomes equal between Ⓐ and Ⓑ.



TRACKING ERROR COMPENSATION ADJUSTMENT

1. Connect CH1 of oscilloscope to the test point ⊕ for **tracking error compensation** of main P.C.B. and the **chassis** ⊖.
   Oscilloscope setting: VOLT 50mV
   SWEEP.....1msec.
   INPUT.....DC
2. Turn the power switch "**ON**", and playback **track 1** of test disc (**SZZP1014F or SZZP1054C**).
3. Adjust **VR106** so that the waveform on the oscilloscope is DC level **0±5mV**.

PLL ADJUSTMENT

1. Connect CH1 of oscilloscope to **LINE OUT terminal** (L or R) of main P.C.B. and the chassis (−).
   Oscilloscope setting: VOLT 1V
   SWEEP.....1msec.
   INPUT.....DC
2. Turn the power switch "**ON**" and playback **track 7** of test disc (SZZP1054C).
3. Slowly adjust **VR301** while watching the waveform on the oscilloscope.
   ⓐ Turn VR301 clockwise until the waveform begins to be disturbed, and then remember the position.
   ⓑ Next, turn VR301 counterclockwise and remember the position where the waveform begins to be disturbed.
   ⓒ Set VR301 to the middle of the positions remembered.





CHECK OF PLAY OPERATION AFTER ADJUSTMENT

- **Skip search check**
  1. Play back a common disc.
  2. Press the skip button and check that skip search can be done. (Both forward and reverse)
- **Manual search check**
  1. Play back a common disc.
  2. Press the manual serach button and check that manual search can be smoothly done at low and high speeds. (Both forward and reverse)
- **Check for defect**
  1. Play back the black spot of test disc and check for sound skip or noise.
  2. Play back the finger print of test disc and check for sound skip or noise.

OPTICAL PICK-UP ADJUSTMENT

Measuring Instruments and Special Tools

- Two-channel oscilloscope (with EXT trigger) of 30MHz or over
- Test disc (SZZP1014F, SZZP1054C, SZZP1056C)
- Hexagonal wrench (SZZP1044C)

Adjustment Procedure and Adjustment Point

- If the optical pickup is replaced, adjust it according to the following procedure.

Step 1: Assemble the set to get ready for power ON.
↓
Step 2: Make the temporary setting of each VR. ..... 1 page
↓
Step 3: Adjust the hight of turntable. ..... 7 page
↓
Step 4: Adjust the mechanical. ..... 7 page
↓
Step 5: Make the electric adjustment. ..... 2 page

Adjustment point



TURNTABLE HEIGHT ADJUSTMENT

1. Connect CH1 of the oscilloscope to **TJ102** (+) of main P.C.B. and **chassis** (−).
   Oscilloscope setting: VOLT 100mV
   SWEEP.....5msec.
   INPUT.....DC
2. Set the DC zero balance of the oscilloscope.
3. Turn the power switch "**ON**" and play back the test disc (SZZP1014F or SZZP1054C).
4. Turn the **adjusting** screw so that the center of waveform on the oscilloscope is **0±50mV**.
   (Insert a flat head screwdriver from the bottom of the set as shown.)
5. After the adjustment, apply **screw-lock paint** (RZZOL01) to the adjusting screw.





MECHANICAL ADJUSTMENT

1. Connect CH1 of the oscilloscope to **TJ301** (+) and **TJ302** (−) of main P.C.B.
   Oscilloscope setting: VOLT 500mV
   SWEEP.....0.5µsec.
   INPUT.....AC
2. Turn the power switch "**ON**" and play back the **track 9** of test disc (SZZP1056C).
   (If any track other than track 9 is playback, this adjustment cannot be achieved.)
3. Shift the set as shown with it played back. (If the set is reversely shifted, it cannot be completely adjusted.)
4. Alternately turn the Mechanical adjusting screws (2 pcs.) so that the vertical fluctuation of the waveform (RF signal) on the oscilloscope is minimized.
5. After the adjustment, apply **screw-lock paint** (RZZ0L01) to the adjusting screw.





Printed in Japan
861008000 Ⓗ AM

Adjustment Manual

■ MEASUREMENTS AND ADJUSTMENTS

• **Adjustment Points**



• **Temporary Setting of Each VR**



ELECTRICAL ADJUSTMENT

Caution:
- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.) With the unit turned "on", laser radiation is emitted from the pickup lens. Be careful during adjustments in particular.

Measuring Instruments and Special Tools

- Servo gain adjuster (SZZP1017F)
- Test disc
  Test disc (SZZP1014F) old and new type
  Inspection test disc (SZZP1054C)
  Unever disc (SZZP1056C)
  Black band disc (SZZP1057C)
- Ordinary disc
- Two-channel oscilloscope (with trigger) of 30MHz or over
- Low frequency oscillator
- Conversion connector (SZZP1032F)

Adjustment procedure

Step 1: Remove the cabinet.

Step 2: Connect the servo gain adjuster. ..... 2 page

Step 3: Make the temporary setting of each VR. ..... 1 page

Step 4: Best eye (PD balance) adjustment. ..... 3 page

Step 5: Focus gain adjustment. ..... 3 page

Step 6: Tracking gain adjustment. ..... 3 page

Step 7: Make the temporary adjustment of focus, tracking offset. ..... 4 page

Step 8: Focus offset adjustment. ..... 4 page

Step 9: Tracking offset adjustment. ..... 5 page

Step 10: Tracking error compensation adjustment. ..... 5 page

Step 11: PLL adjustment. ..... 5 page

Step 12: Check of operation after adjustment. ..... 6 page

Connection of servo gain adjuster



BEST EYE (PD BALANCE) ADJUSTMENT

1. Connect CH1 of the oscilloscope to **TJ301** (+) and **TJ302** (−) of the main P.C.B.
   Oscilloscope setting: VOLT 500mV
   SWEEP.....0.5µsec.
   INPUT.....AC
2. Turn the power switch "**ON**", then playback the test disc (**SZZP1014F or SZZP1054C**).
3. Adjust **VR101** so that the eye pattern of RF signal is stretched to maximum.



FOCUS GAIN ADJUSTMENT

1. Set the low frequency oscillator to **750Hz** and an output voltage **150mVp-p**, then connect the oscillator to the terminals **OSC** and **GND** of the servo gain adjuster.
2. Connect CH1 and CH2 of the oscilloscope to **TP1** and **TP2** of the servo gain adjuster.
   (**TP3** is the grounding terminal.)
   Oscilloscope setting: VOLT 100mV
   (both channels)
   SWEEP.....1msec.
   INPUT.....DC
3. Set the servo gain adjuster switch to "**2**".
   (ON/OFF switch to "**ON**")
4. Turn the power switch "**ON**", then playback the test disc (**SZZP1014F or SZZP1054C**)
5. With the servo gain adjuster switch set to "**1**", **750Hz** signal is given in the oscilloscope. Then adjust **VR104** so that the waveforms of **both channels** become equal to each other.



Make a=b

TRACKING GAIN ADJUSTMENT

1. Set the low frequency oscillator to **1.2kHz** and an output voltage **150mVp-p**, then connect the oscillator to the terminals **OSC** and **GND** of the servo gain adjuster.
2. Connect CH1 and CH2 of the oscilloscope to **TP1** and **TP2** of the servo gain adjuster.
   (**TP3** is the grounding terminal.)
   Oscilloscope setting: VOLT 100mV
   (both channels)
   SWEEP.....1msec.
   INPUT.....DC
3. Set the servo gain adjuster switch to "**2**".
   (ON/OFF switch to "**ON**")
4. Turn the power switch "**ON**", then playback the test disc (**SZZP1014F or SZZP1054C**)
5. With the servo gain adjuster switch set to "**3**", **1.2kHz** signal is given in the oscilloscope. Then adjust **VR102** so that the waveform of **both channels** become equal to each other.
6. The servo gain adjuster is not necessary for other adjustment. So, remove the connection and attach the short connector to CN102.



Make a=b

FOCUS, TRACKING · OFFSET TEMPORARY ADJUSTMENT

(FOCUS OFFSET TEMPORARY ADJUSTMENT)

1. Connect **CH1** of oscilloscope to **TJ102** (+) and **chassis** (−).
   Oscilloscope setting: VOLT 100mV
   SWEEP.....5msec.
   INPUT.....DC
2. Turn the power switch "**ON**", then playback the test disc (**SZZP1057C**).
3. After reading TOC, set the mode to **STOP**.
4. Adjust **VR105** so that DC level on the oscilloscope becomes **ground level (0V)**.

(TRACKING OFFSET TEMPORARY ADJUSTMENT)

1. Connect **CH1** of oscilloscope to **TJ101** (+) and **chassis** (−).
   Oscilloscope setting: VOLT 100mV
   SWEEP.....5msec.
   INPUT.....DC
2. Turn the power switch "**ON**", then playback the test disc (**SZZP1057C**).
3. After reading TOC, set the mode to **STOP**.
4. Adjust **VR105** so that DC level on the oscilloscope becomes **ground level (0V)**.



FOCUS OFFSET ADJUSTMENT

1. Connect CH1 of the oscilloscope to the **TJ301** (+) and **TJ302** (−). Connect CH2 to the **TJ102** (+) and **TJ302** (−) of the main P.C.B.
   Oscilloscope setting: VOLT 500mV (CH1)
   100mV (CH2)
   SWEEP.....0.5msec.
   INPUT.....AC (CH1)
   DC (CH2)
   MODE.....NORM
   (Triggering via CH1)
2. Turn the power switch "**ON**", and playback **track 9** (black band) of test disc (**SZZP1057C**).
3. Trigger so that waveforms appear on the oscilloscope, and adjust VR105 so that the depression of RF of CH1 Changes to a smooth envelope and that the waveform amplitude of CH2 is minimized or becomes equal between Ⓐ and Ⓑ.


NG


OK



• **Rear panel**



• **Remote control unit**

SH-R51..... For U.S.A. and Canada (Black Type)
SH-R52..... For others (Black Type)
SH-R52S ..... For others (Silver Type)



Playing a disc

All of the examples on pages 6~9 refer to disc which contains 7 tracks and has a total playing time of 49 minutes and 58 seconds, as shown below.



1 Automatic play (To play a disc from beginning to end.)

1 **Press to turn on (⏻→⏻).**
(See ① below.)

3 **Insert a disc with the label side facing upward.**
(See ② below.)



5 **Press ▶ to start play.**
(See ⑤, ⑦ below.)

■ **Press to resume play.**
(See ⑦ below.)



■ **Press ⏸ to briefly interrupt play.**
(See ⑥ below.)

■ **Press ■ to stop play.**
(See ⑧ below.)

2 **Press ⏏ to open disc holder.**

4 **Press ⏏ to close disc holder.**
(See ②, ③ and ④ below.)

① Display momentarily illuminates as shown below:



② Insert the disc only after the disc holder has opened all the way. If the disc is inserted too soon, it may be damaged. Do not tilt the player while the disc holder is opening or closing since the disc could fall out of the holder.

③ Step 4 can be skipped by pressing the play button after inserting a disc. In this case, the holder will close and disc play will begin immediately from track 1, but the tracks and total playing time will not be displayed.

④ Disc data is being read.



Stop mode



⑤ When a disc having no indexes is played " / " is constantly displayed in the index section.



Flashes on and off. Index number

If the play button is pressed during disc play, disc play is started again from the first track (**auto-return play function**).

⑥ The play indicator (▶) goes out, the pause indicator (❚❚) illuminates and the unit switches to the pause mode.

⑦ The pause mode is cancelled, play is resumed, and the play indicator illuminates.

⑧ The pickup will return to the beginning of the first track and the unit will switch to the stop mode.

⑨ When the end of the disc is reached, the pickup returns to the beginning of the first track and the unit switches to the stop mode.
- Remove the disc from the disc holder.
- Turn off the power if the unit is not to be used again for a while.

- Since steps 1, 2, 3, 4 and 6 in this procedure are the same for all disc play procedures, they are not included in the following explanations.

2 Program play

Note:
- Press the repeat button before starting program play if you wish to skip backward during program play.

1 While watching the track number display, press momentarily to specify the desired track number. (See ① below.)

2 Press memory **to enter the displayed track number into memory.** (See ② below.)

3 Repeat steps 1 and 2 until the desired programming is complete. (See ③ below.)

4 Press ▶ to start play.
- Play begins from the first programmed track.



① -E (error) will be displayed if a track number not on the disc is specified.

② If more than 20 selections are entered, " -F " (full) is shown in the display panel and no further selections can be programmed.
The total track time is also displayed if entires are made when the unit is in the stop mode.

③ To enter the same track number several times in succession, simply press the memory button the same number of times that the track is to be played.
Each entry counts as one selection.

- During programming and program play, track numbers from 1 to 20 are displayed. The > indicator will illuminate if the disc contains more than 20 tracks and the "-F" indicator will illuminate when a track number higher than 20 is programmed. When a track number higher than 20 is played, the ">" indicator will flash on and off.

- If you make a mistake when entering a track number, press the clear button to cancel that entry. Each time the clear button is pressed, the previous entry is cleared.
Note:
The clear function will operate only after the memory button has been pressed.
However, if the clear button is pressed during disc play, the entire program is cleared and disc play continues from the current point to the end of the disc.
Entering additional program selections during play:
During play, additional program entries can be made in the same manner as at the time of programming (see above).
- Additional program selections can be entered until a total of 20 selections are programmed.
- If more than 20 selections are entered, -F (full) is shown in the index-number display section of the display panel and further program entries are not accepted.
- All program entries are cancelled when the stop button is pressed, or power is turned off.

■ Program confirmation

Press the recall button on the remote-control unit to display the programmed track numbers.
In the example, tracks 3, 5, and 1 are programmed in that order and track 3 is currently being played.

When the recall button is pressed, programmed track (and index) numbers are displayed one by one in the order in which they are to be played.



3 Random access play

■ Track random access

Example: To play a disc from track 3 to the end of the disc.



1 Press the numeric button 3 to specify track 3. (See ① below.)

2 Press ▶ to start play. (See ② below.)

① The display shows track 3 specified.



② The play indicator (▶) illuminates and play begins from track 3.



Border flashes on and off as the corresponding track is played.

Note:
If a track number that is non-existent on the disc is programmed the letter "-E" (error) in the display will be displayed.

■ Index random access (When specifying an index number obtained from the disc's liner note)



For example: To play from index 2 of track 3 to the end of the disc.

1 Press the numeric button 3 to specify track 3. (See ① below.)

2 Press index. (See ② below.)

3 Press the numeric button 2 to specify index 2. (See ③ below.)

4 Press ▶ to start play. (See ④ below.)



①



When playing discs having only one track, remember to enter track number 1, then specify index number.

②



③ Index number is displayed.



Selection can be made up to a maximum of 99.

④ The play indicator (▶) illuminates and disc play begins from index 2 of track 3.



Flashes on and off

If a index number that is non-existent on the disc is programmed, the last index track will be played.

When the end of the disc is reached, the player switches to the stop mode.

4 Skip play
(During play or in the pause mode.)

■ Forward or backward track skip play

While watching the track number display, press the forward or backward skip button momentarily to locate the desired track.

(See ① below.)

⏭ :
Forward skip button
(Pickup skips forward)

⏮ :
Backward skip button
(Pickup skips backward)

① When either of these buttons is held down, tracks are skipped continuously (quick skip mode).

Forward skip

- During automatic play, the pickup skips to the beginning of the next track each time the button is pressed.
- During program play or program repeat play, the pickup skips to the beginning of the next programmed track each time the button is pressed.

Backward skip

- During automatic play, the pickup skips to the beginning of the current track. If pressed again quickly, the pickup skips to the beginning of the previous track.

5 Search play (forward/backward)

This function allow search to any desired point on the disc.
Search play can be performed as required using either the search dial or the forward/backward search buttons on the remote control unit.
The position of the pickup is confirmed by watching the display panel or listening to the sound from the compact disc.

1 Press the dial search speed selector to activate dial search and to select high or low speed for dial search.

The dial search indicator (F) illuminates.
The dial search speed indicator (S) for "slow" or "fast" illuminates also.

2 Turn the search dial clockwise for forward search and counterclockwise for backward search.

■ When the remote control unit is used, the desired position can be found at a constant search speed. (See page 16.)

- During program play, the pickup can only be moved between the beginning and end of the track currently being played.
- The search speed changes according to the speed the search dial is turned, however, it will not become faster or slower than its determined limits.
- The search speed is different during play and while the unit is in the pause mode.

■ HANDLING PRECAUTIONS FOR OPTICAL PICKUP

The laser diode in the optical pickup may break down due to potential difference caused by static electricity of clothes or human body.
So, be careful of electrostatic breakdown during repair of the optical pickup.

• Handling of optical pickup

1. Do not give excessive shock to the optical pickup because it is of extremely precise structure.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board. **(FPC board)**
   When removing or connecting the short pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board. **(FPC board)**
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.



• Grounding for electrostatic breakdown prevention

1. Human body grounding
   Use the anti-static wrist strap to relieve the static electricity from your body.
2. Work table grounding
   Put a conductive material (sheet) or steel sheet on the area where the optical pickup is placed, and ground the sheet.

Caution:
The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the optical pickup.





■ DISASSEMBLY INSTRUCTIONS

CAUTION:
- It is very dangerous to look at or touch laser radiation. (Laser radiation is invisible.)
- With the unit turned "on", laser radiation is emitted from the pickup lens.
- When doing the job, removing the cabinet and disc clamper of this unit, be sure to turn the power supply off.

Ref. No. 1	How to remove the cabinet
Procedure 1	• Remove the 5 set screws.



Note: When doing the job, Lock the lock shaft at bottom of the unit. (see page 3)

Ref. No. 2	How to remove the front panel
Procedure 1 → 2	• Remove in the numerical order shown.


Pull out the flat cable while pressing the connector.
Push here
CN401～405
5
Remove it from the chassis tab.
2 Pull out the connector (CN801).
6 Remove in the direction of the arrow.
1 Remove the setscrew.
3 Remove the flat cable.
4 Remove it from the chassis tab.

Ref. No. 3	How to remove the operation P.C.B.
Procedure 1 → 2 → 3	1. Remove the search dial knob and nut. 2. Release the 4 claws of the remote sensor and disc LED P.C.B. 3. Remove the 4 setscrews. 4. Release the claw of the operation P.C.B.



Ref. No. 4	How to remove the headphones P.C.B.
Procedure 1 → 2 → 4	• Release the 4 claws.



Ref. No. 6	How to remove the disc clamper
Procedure 1 → 6	• Remove the setscrew.



1. Be sure to connect the P.C.B. ground terminal (Line out terminal) and chassis with a lead wire.
2. Connect the ground wire of loading base to the chassis.



Ref. No. 5	How to remove the main P.C.B.
Procedure 1 → 2 → 5	1. Remove the 6 setscrews. 2. Lift the P.C.B. to remove it from the chassis tab. 3. Remove in the direction of the arrow.



How to check the main P.C.B.

- When checking the soldered surfaces of main P.C.B. and replacing the parts, do as shown.

1. Remove the FPC board.
Caution: Insert the short pin into the FPC board in order to prevent breakdown of laser diode. (See page 10)



2. Mount FPC junction P.C.B. (SZZP1070C) on the chassis. (Do the job as shown by using the main P.C.B. setscrew.)
3. Connect FPC board from optical pickup to FPC junction P.C.B.
4. Connect FPC extension board (SZZP1071C) to FPC junction P.C.B. and CN101 of main P.C.B.



Ref. No. 7	How to remove the loading base
Procedure 1 → 2 → 7	Refer to the optical pickup handling precautions (See page 10).

1. Turn the drive gear in the direction of arrow Ⓐ, and shift the disc holder forward.
2. Remove the 4 setscrews.

Caution: The color of each spring, they must be reinstalled in their original position.

3. Pull out the 4 connectors (CN1, CN104, CN302, CN407).
4. Remove the FPC board (CN101).





Ref. No. 8	How to remove the disc holder (disc tray)
Procedure 1 → 2 → 6 → 8	

- **Set the drive gear as shown below.** (Turn it completely to the right, then turn it to the left by about 20° so that drive gear teeth or projection will not touch the rack of disc holder.)



- **To remove the drive gear**
  Remove the screw Ⓐ of leaf switch (S101), then remove the drive gear setscrew Ⓑ.

1. Push the holder lever backward, (From underneath the loading base.)
2. Pull the disc holder and bend the 2 claws of disc holder stopper of loading base toward the optical pickup.
3. Further pull out the disc holder to remove it.



- **Caution for fitting**
  When fitting the disc holder, make the drive gear as shown on the left, and then insert the disc holder along the guide of loading base.
  After inserting the disc holder completely, turn the drive gear to the right completely.

Ref. No. 9	How to remove the optical pick up
Procedure 7 → 8 → 9	• Remove in the numerical order shown. **Note:** Lock the lock shaft at the bottom of the unit.

Refer to the optical pickup handling precautions (See page 10).

1 Remove the screw.



2 Remove the resistance unit.

3 Unsolder the 2 terminals.

5 Remove the 3 setscrews Ⓐ.



6 Pull out the optical pickup from the 2 guide shafts.

4 Remove the 2 setscrews Ⓑ. (Underneath)

Ref. No. 10	How to remove the drive motor
Procedure 7 → 10	• Remove in the numerical order shown.

2 Remove the 2 setscrews.



1 Remove the drive belt.

5 Lift up the drive motor.

3 Remove the setscrew.



4 Release the 2 Tabs in the direction of the arrows.

Ref. No. 11	How to remove the power transformer
Procedure 7 → 11	

1. Remove the connector (CN1).
2. Remove the 3 setscrews.
3. Remove it from the chassis tab.
4. Remove in the direction of the arrow.



Note: When replacing the power transformer, do as shown.



■ HOW TO REPLACE IC'S (Small outline type)

	Replacing procedure		Cautions
1	Reduce the amount of solder on each pin of the integrated circuit by use of a solder sucker.	(Example) H–130 	• Recommended tool .....Special soldering iron * H605M and H-130. * H605E and H-130. • Do not touch the soldering iron to the area for a long time. It may otherwise cause removal of the print foil. • When shifting the pin upward, do the job quickly while the solder is melting. If the solder is hard, it may cause removal or breakage of the print foil. • When using a pencil type soldering iron. 1. Completely remove the solder from each IC pin by use of solder sucker. 2. Raise each pin by means of an eyeleteer, hold the pliers then remove IC package from P.C.B.
2	Melt the solder on the pin (one electrode) with the soldering iron.		
3	While the solder is melting, shift the pin upward by the soldering iron to remove it from the foil.		
4	Remove each pin from the foil according to the above-mentioned procedure.		

*** Special soldering iron**
(Refer to Technical Information, ORDER NO. GAD84125486T1)...For U.S.A. and Canada
(Refer to Technical Information, ORDER NO. GAD84115476T8)...For others

•H–605 Spot Heater (hot-air solder iron)
This device that uses hot air to melt solder was developed to remove Flat-Package ICs, RHCs and chip parts.

- H–605M (For 120V power source)
- H–605E (For 200V/220V/240V power source)





•H–617 Twin Nozzle (for spot heater)
Special nozzle for the removal of RHCs and chip resistors. (Nozzle diameter: 1.0mm×2)

•H–130 Slim Pencil Solder Iron
An ultrasmall ceramic heater solder iron is extremely handy for soldering chip parts, RHCs, ICs etc., to high-density circuit boards.
Features:
- Rated power: 100V, 15W
- Max. temp.: 400°C
- Heater: ceramic (long life)
- Insulation resistance: 100MΩ
- Length: 178mm
- Weight: 16g (not including cord)

•H–131, H–V13 Cap Bits
Solder tip for the slim pencil Solder Iron is composed of a bit holder and a corrosion resistance solder tip.
Permits changing of solder tips even while still hot.
- Solder tip: 0.3mm

■ TERMINAL FUNCTION OF LSI

• MN15283PDP (System Control and FL Drive)

Pin No.	Mark	Singnal	I/O Devision	Function
1	VSS	GND	I	GND terminal
2	X0	——	O	Not used (Open)
3	X1	SENSE	I	Optical servo condition input
4	P00	MRLY	O	Muting control signal (muting ON at "H")
5	P01	M DATA	O	Command data output
6	P02	MCLK	O	Command clock output
7	P03	MLD	O	Command load output
8	P10	——	I	Search dial signal input
9	P11	——	I	Search dial signal input
10	P12	——	——	Not used (Open)
11	P13	——	——	———
12	$\overline{SYNC}$	——	——	Not used (Open)
13	$\overline{RST}$	RESET	I	Reset signal input (reset at "L")
14	$\overline{IRQ}$	BLKCK	I	Sub-code block (Q data) clock (75Hz) input
15 ⟆ 18	P50 ⟆ P53	KEY	I	Key scan input
19	$\overline{SBT}$	$\overline{CLDCK}$	I	Sub-code frame clock (7.35kHz)
20	$\overline{SBD}$	SUBQ	I	Sub-code Q data input
21	P20	SEEK	——	———
22	P21	——	——	Not used (Open)
23	P22	$\overline{TRV\text{-}R}$	O	Traverse reverse command signal
24	P23	$\overline{RRV\text{-}F}$	O	Traverse forward command signal
25	P30	CNT4	O	Optical servo IC control signal (KICKR: Kick direction [Reverse] command)
26	P31	CNT3	O	Optical servo IC control signal (KICKF: Kick direction [Forward] command)
27	P32	CNT2	O	Optical servo IC control signal (TRON: Tracking servo)
28	P33	CNT1	O	Optical servo IC control signal (FOON: Focus servo)
29	P40	STAT	I	Processing status input from signal processing LSI traverse position detection
30	P41	COMP	——	Not used (Open)
31	P42	$\overline{FLOCK}$	I	Optical servo condition (focus) input
32	P43	$\overline{SENSE}$	I	Optical servo condition (track cross) input
33	P60	$\overline{CLOSE}$	O	Loading motor close command (ON at "L")
34	P61	$\overline{OPEN}$	O	Loading motor open command (ON at "L")
35	DAC	DAC	O	———
36	VPP	——	I	FL drive power supply (connected to −32V)
37 ⟆ 52	D0 ⟆ DD	——	O	FL grid signal and key scan signal
53 ⟆ 61	S8 ⟆ S0	——	O	FL anode signal
62	VDD	——	I	Power supply (connected to +5V)
63	OSC2	——	I	Clock terminal
64	OSC1	——	I	Clock input

• MN1550PDM (Remote Control Signal Processing)

Pin No.	Mark	Singnal	I/O Devision	Function
1	VDD	——	I	Power supply (connected to +5V)
2	OSC	SMCK	I	Clock input
3	P23	——	——	———
4	P22	——	——	———
5	RST	RESET	I	Reset signal input
6	P21	——	——	———
7	P20	——	I	Remote control signal input
8	IRQ	——	I	Program enable/de-enable control
9	P31	——	——	———
10 ⟆ 13	P10 ⟆ P13	Data	I	Key strobe
14 ⟆ 17	P00 ⟆ P03	Data		
18	VSS	GND	I	GND terminal

• MN6617 (Digital Signal Processing: EFM Decoder, Error Correction, CLV Servo)

Pin No.	Mark	I/O Devision	Function
1	BLKCK	O	Sub-code block (Q data) clock (75 Hz)
2	$\overline{\text{CLDCK}}$	O	Sub-code frame (Q data) clock (7.35 kHz)
3	$\overline{\text{SUBQ}}$	O	Sub-code (Q data) output
4	CRC	O	Sub-code (Q data) CRC check (Not used, open)
5	$\overline{\text{RST}}$	I	Reset signal input (reset at "L")
6	MLD	I	Command load input
7	MCLK	I	Command clock input
8	MDATA	I	Command data input
9	DMUTE	I	Muting control (muting ON at "H")
10	$\overline{\text{TRON}}$	I	Tracking servo ON signal (tracking servo ON at "L")
11	STAT	O	Processing condition (CRC, OTC, CLVOK, TT STOP) output
12	SMCK	O	Clock output (4.2336 MHz)
13	PMCK	O	Pitch control clock output Not used, open)
14	ITC	I	Track counter input signal (Not used, open)
15	$\overline{\text{TEST}}$	I	Test mode selection (Not used, connected to +5 V)
16	X2	O	Clock output (16.9344 MHz)
17	X1	I	Clock input (16.9344 MHz)
18	SEL	I	DA output parallel/serial selection (serial at "L")
19	LDG/WDCK	O	L channel deglitch signal/serial data word clock. (Not used, open)
20	RDG	O	Spindle motor control clock signal
21	DEMPH	O	De-emphasis ON signal (de-emphasis ON at "H")
22	IPFLAG	O	Interpolation flag (interpolation at "H")
23	FLAG0	O	Error flag (error at "H")
24	FLAG6	O	16 K RAM address reset signal (reset at "H")
25	XCK	O	Clock (16.9344 MHz) output
26	DA15/ SRDATA	O	16-bit data output/serial data output (MSB first)
27	DA14/ SRDATAX	O	16-bit data output/serial data output (LSB first)
28	DA13/SRCK	O	16-bit data output/serial data beat clock
29	DA12/WDCK	O	16-bit data output/serial data word clock (Not used)
30	DA11/ BYTCK	O	16-bit data output/serial data byte clock (Not used)
31	GND	I	GND terminal
32	DA10/R/L	O	16-bit data output/R/L signal
33	DA9/RESY	O	16-bit data output/ Resynchronizing signal
34	DA8/FCLV	O	16-bit data output/Synchronizing detection signal (Nor used)
35	DA7/ IPBYTE	O	16-bit data output/Interpolation flag for each byte (Not used)
36	DA6/IPSEL	I/O	16-bit data output/ interpolation inhibit (Nor used)
37	DA5/FLAG5	O	16-bit data output/C2 decoder correction flag 3 (Not used)
38	DA4/FLAG4	O	16-bit data output/C2 decoder correction flag 2 (Not used)
39	DA3/FLAG3	O	16-bit data output/C2 decoder correction flag 1 (Not used)
40	DA2/FLAG2	O	16-bit data output/C1 decoder correction flag 2 (Not used)
41	DA1/FLAG1	O	16-bit data output/C1 decoder correction flag 1 (Not used)
42	DA0/FLCK0	O	16-bit data output/Crystal frame clock
43 ∫ 50	D7 ∫ D0	I/O	16 K RAM data output
51	RAMOE	O	16 K RAM $\overline{\text{OE}}$ signal
52	RAMWE	O	16 K RAM $\overline{\text{WE}}$ signal
53 ∫ 63	RAMA 0 ∫ RAMA10	O	16 K RAM address signal (RAMA0: LSB, RAMA10: MSB)
64	PC	O	Spindle motor ON signal (ON at "L")
65	EC	O	Spindle motor drive signal
66	FG	I	Spindle motor FG signal input
67	VCNT	——	———
68	REXT	——	———
69	VDD	I	Power supply (connected to +5 V)
70	PD	——	———
71	PCKO	——	———
72	PCK	I	PLL extract clock input
73	VDD	I	Power supply (connected to +5 V)
74	EFM	I	EFM signal input (PLL)
75	SRF	I	EFM signal input (DSL)
76	DO	I	Drop-out signal (Drop-out at "H")
77	CLVS	O	11T servo OK signal (OK at "H")
78	FPC	O	PLL frequency comparision signal
79	RSSEL	O	PLL frequency in take operation signal
80	SRFO	——	———
81	NSRF	——	———
82	RF	——	———
83	SUBC	O	Sub-code serial output data
84	SBCK	I	Clock for sub-code serial output

• AN8370S (Optical Servo Control)

Pin No.	Mark	I/O Devision	Function
1	VEE	I	Power supply (connected to −5 V)
2	LSA	I	Phase difference input (A)
3	GND	I	GND terminal
4	LSB	I	Phase difference input (B)
5	APC	O	Auto laser power control output
6	TEOUT	O	Tracking error signal output
7	TEG	I	Tracking error gain adjusting input
8	TE+	I	Phase difference-voltage conversion (+)
9	TE−	I	Phase difference-voltage conversion (−)
10	APC−	O	Laser Power inversion input
11	C•MEM	I	Capacitor connection for phase difference memory
12	APC+	I	Laser power non-inversion input
13	VREF	O	Reference current generation
14	SENSE	O	Selector output (track-crossed)
15	HIN	I	Tracking hold circuit input
16	HOUT	O	Tracking hold circuit output
17	SPCNT	O	Track-cross speed control output (not used, open)
18	C•MSP	I	Track-cross reference speed setting capacitor connection (not used, open)
19	C•AF	I	Auto focus timer capacitor connection
20	KICK R/$\overline{\text{F}}$	O	Track kick signal output
21	VCC	I	Power supply (connected to +5 V)
22	CNT1	I	Control input ($\overline{\text{FOON}}$: Focus servo ON signal)
23	CNT2	I	Control input ($\overline{\text{TRON}}$: Tracking servo ON signal)
24	CNT3	I	Control input (KICKF: Kick direction [forward] command)
25	CNT4	I	Control input (KICKR: Kick direction [reverse] command)
26	$\overline{\text{F•LOCK}}$	O	Focus lock signal output
27	C•FBDO	O	Capacitor connection for inversion RF high speed detection
28	C•SBDO	O	Capacitor connection for inversion RF low speed detection
29	C•SBRT	O	Capaictor connection for non-inversion RF low speed detection
30	C•FBRT	O	Capacitor connection for non-inversion RF high speed detection
31	RF OUT	O	RF signal output
32	BDO	O	Drop-out detection output
33	RFIN	I	RF signal input
34	S•OUT	O	Focus search signal output
35	C•LW	I	Capacitor connection for triangular wave generation
36	FE•OUT	O	Focus error signal output
37	FEG	I	Focus error gain adjusting input
38	FE•REF	I	Focus error comparision voltage generation
39	PDB	I	Photo detector current input (B)
40	IVB	O	Current/voltage conversion output (B)
41	IVA	O	Current/voltage conversion output (A)
42	PDA	I	Photo detector current input (A)

• EHDGA1243 (Data Slice and PLL)

Pin No.	Mark	I/O Devision	Function
1	PCK	O	Clock output extracted from SRF
2	EFM	O	EFM signal output synchronized with PCK
3	D•GND	I	GND terminal (digital system)
4	SRF	O	RF signal output data-sliced into digital value
5	SLC	I	Slice level control signal input
6	DC	O	Drop-out detection pulse output
7	FPC	I	Frequency comparison error signal input
8	VCC	I	Power supply (connected to +5 V)
9	NC	——	Non connection
10	VR	I	Resistor connection for VCO oscillation frequency
11	VEE	I	Power supply (connected to −5 V)
12	VC1	I	Capacitor connection for VCO oscillator frequency
13	VC2	I	Capacitor connection for VCO oscillator frequency
14	A•GND	I	GND terminal (analog system)
15	RF	I	RF signal input

• MN6618A (Digital Filter)

Pin No.	Mark	I/O Devision	Function
1	———	———	———
2	D012	O	16-bit parallel data output
3	D011/SCK	O	16-bit parallel data output/ serial output bit clock
4	D010/SOUT	O	16-bit parallel data output/ serial output data
5	GND	I	GND terminal
6	D09	O	16-bit paralled data
7	———	———	———
8	D08	O	16-bit parallel data
9	D07	O	16-bit parallel data
10	———	———	———
11	———	———	———
12	D06	O	16-bit parallel data
13	D05	O	16-bit parallel data
14	D04	O	16-bit parallel data
15	D03/LRCK	O	16-bit parallel data/RL signal
16	———	———	———
17	———	———	———
18	D02/WCK	O	16-bit parallel data/serial output word clock
19	D01	O	16-bit parallel data
20	D00	O	16-bit parallel data (LSB)
21	MDATA	I	Command data input
22	———	———	———
23	MCLK	I	Command clock input
24	MLD	I	Command load input
25	———	———	———
26	$\overline{RST}$	I	Reset signal input (reset at "L")
27	———	———	———
28	LRCK	I	R/L signal
29	———	———	———
30	SFT	I	Serial data input clock
31	SIN	I	Serial data input
32	———	———	———
33	X OUT	O	Clock output (Not used)
34	X IN	I	Clock input (16.9344 MHz)
35	OSEL	I	DA output parallel/serial selection (parallel at "L")
36	LDGL	O	L channel deglitch signal
37	RDGL	O	R channel deglitch signal
38	VDD	I	Power supply (connected to +5V)
39	D015	O	16-bit parallel data (MSB)
40	D014	O	16-bit parallel data
41	———	———	———
42	D013	O	16-bit parallel data

• AN8290S (Spindle Motor Drive)

Pin No.	Mark	I/O Devision	Function
1	GND	I	Minimum potential of IC control. (In this unit, it is connected to VEE [−7.6V].)
2	DCR	I	Standard voltage of FA1, PC, CLK. (In this unit, it is connected to 2.5V.)
3	FAI	I	Torque command filter amp. input. (Normal rotation command when FAI < DCR.)
4	FAO	O	Filter amp. output.
5	D1	I	Absolute value circuit input.
6	LPF	I	Capacitor terminal for low pass filter of current feedback loop.
7	A1	O	Drive signal output.
8	A2	O	
9	A3	O	
10	PGND	1	Minimum potential of IC power. (In this unit, it is connected to VEE [−7.6V]).
11	CS	I	Dive current detection resistor terminal.
12	PVCC	I	Power input for IC power.
13	H3−	I	Not used in this unit.
14	H3+	I	
15	H2−	I	Negative output of Hall element is input.
16	H2+	I	Positive output of Hall element is input.
17	H1−	I	Negative output of Hall element is input.
18	H1+	I	Positive output of Hall element is input.
19	HSW	I	Bias switch of Hall element. (OFF when PC > DCR)
20	HB	I	Bias power of Hall element.
21	VCC	I	Power input for IC control.
22	PC	I	Power control. (Power down mode when PC > DCR)
23	CLK	I	Clock input. (DCR standard, operated at the edge of rise.)
24	TC	I	Triangular wave generation capacitor terminal.

■ TROUBLESHOOTING

Notes:

1. Before using this unit, release the lock shaft which secures the pick-up at the bottom of the unit.
2. Carefully handle the compact disc because stains, dust or warping may cause generation of noise.
3. For the voltage value and waveform, refer to the schematic diagram. (The voltage value and waveform slightly varies depending on the measuring set and tester.)
4. The possible defects are mainly shown by semiconductors. The adjacent electronic circuits (C, R, etc.) are omitted.

● Power circuit check



● Focus servo check



● Tracking servo check


Ⓑ
● Traverse servo check
KICK pulse is given during forward skip ? (IC401, pin 24)
NO
IC101 IC401 defective
YES
KICK pulse is given during backward skip ? (IC401, pin 23)
NO
IC101 IC401 defective
YES
Pulse signal is emitted during search dial rotation ? (IC401, pins 8, 9)
NO
VR601 defective
YES
Optical PU speed/position detecting signal is emitted ? (CN104, pin 3 optical PU inner periphery "0.3 V", outer periphery 3.5 V)
NO
Sensor (resistor unit) is defective.
YES
Traverse coil drive signal is emitted ? (Q101, emitter)
NO
IC103 Q101 Q102 defective
● CLV servo check
TRON signal is "L (0 V)" ? (IC301, pin 10)
NO
IC101 IC301 defective
YES
SRF signal is emitted ? (IC304, pin 4)
NO
IC304 defective
YES
Spindle motor ON signal is "L (0 V)" ? (CN302, pin 6)
NO
IC301 IC501 defective
YES
Spindle motor control signal is "H (2.4 V)" ?
NO
IC301 defective
YES
Spindle motor control clock pulse is given ? (CN302, pin 5)
NO
IC301 defective
● Loading motor check
Loading motor ON/OFF signal is emitted ? ("L (0 V)" during IC401, pins 33 and 34 operation)
NO
IC401 S101 defective
YES
Ⓒ
Ⓒ
Loading motor drive signal is emitted ? ("H (6.7 V)" during IC403, pins 7 and 9 operation)
NO
IC403 motor defective
● Digital/audio circuit check
EFM signal is emitted ? (IC301, pin 74)
NO
IC301 IC304 defective
YES
PCK signal is emitted ? (Test point TJ303)
NO
IC301 IC304 defective
YES
Serial data beat clock is given ? (IC301, pin 28)
NO
IC301 defective
YES
Serial data is given ? (IC301, pin 26)
NO
IC301 defective
YES
16-bit parallel data is given ? (IC807, pins 2-18)
NO
IC302 IC807 defective
YES
PAM signal is emitted ? (IC807, pin 20)
NO
IC808 IC807 defective
YES
Deglitch signal is emitted ? (IC801, 802, pin 17)
NO
IC302 defective
YES
Sample hold signal is emitted ? (IC801, 802, pin 19)
NO
IC803 defective
YES
AF signal is emitted ? (IC801, 802, pin 3)
NO
IC805 IC801 IC802 defective
YES
Muting relay is operated ? (Q801, collector 5 V)
NO
IC401 Q801 Relay defective
YES
Headphone output signal is emitted ? (CN801, 802, pin 4)
NO
IC806 defective
YES
Signal is emitted at headphone terminal ?
NO
VR851 IC851 defective

■ RESISTORS & CAPACITORS

Notes: * Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
* Bracketed indications in Ref. No. columns specify the area.
Parts without these indications can be used for all areas.

Numbering System of Resistor

Example

ERD	25	F	J	102
Type	Wattage	Shape	Tolerance	Value

ERX	2	AN	J	471
Type	Wattage	Shape	Tolerance	Value $47x10^1$ (ohm)

Numbering System of Capacitor

Example

ECKD	1H	102	Z	F
Type	Voltage	Value	Tolerance	Peculiarity

ECEA	50	M	330
Type	Voltage	Peculiarity	Value ($33x10^0$ microfarad)

Resistor Type	Wattage	Tolerance
ERD : Carbon ERG : Metal Oxide ERX : Metal Film ERQ : Fuse Type Metal ERD□ L : Carbon (chip) ERO□ K : Metal Film (chip) ERC : Solid	10 : 1/8W 12 : 1/2W 25 : 1/4W 1A : 1W 18 : 1/8W S2 : 1/4W S1 : 1/2W 2F : 1/4W 50 : 1/2W 2A : 2W	J : ±5% F : ±1% G : ±2% K : ±10%

Capacitor Type	Voltage	Tolerance
ECE : Electrolytic ECCD : Ceramic ECKD : Ceramic ECQM : Polyester ECQP : Polyproylene ECG : Ceramic ECEA□□□N: Non Polar Electrolytic QCU□ : Ceramic (Chip Type) ECUX : Ceramic (Chip Type) ECF : Semiconductor EECW : Liquid electrolyte double layer capcitor	0J : 6.3V 1A : 10V 1C : 16V 1E : 25V 1H : 50V 1V : 35V 50 : 50V 05 : 50V 2H : 500V 2A : 100V 1 : 100V KC: 400V AC KC: 125VAC (UL) 1J : 63V	C : ±0.25pF J : ±5% K : ±10% Z : +80% −20% P : +100% −0% M : ±20% D : ±0.5pF G : ±2%

Ref. No.	Part No.	Part Code
RESISTORS		
R11, R12	ERDS2TJ102	001 152 2346 4
R13	ERDS2TJ222	001 152 2353 5
R14 ⚠	ERDS2TJ822	001 152 2455 0
R102	ERDS2TJ222	001 152 2353 5
R103	ERDS2TJ273	001 152 2436 3
R104	ERDS2TJ153	001 152 2351 7
R105	ERDS2TJ182	001 152 2352 6
R106	ERDS2TJ473	001 152 2363 3
R107	ERDS2TJ274	001 152 2437 2
R108	ERDS2TJ101	001 152 2421 0
R109, R110	ER0S2TKF4702	001 151 5723 2
R111, R112	ERDS2TJ274	001 152 2437 2
R113, R114	ER0S2TKF4702	001 151 5723 2
R115	ERDS2TJ102	001 152 2346 4
R116	ERDS2TJ472	001 152 2362 4
R117	ERDS2TJ270	001 152 2434 5
R118	ERDS2TJ3R3	001 152 3152 8
R119	ERDS2TJ101	001 152 2421 0
R120	ERDS2TJ270	001 152 2434 5
R121	ERDS2TJ3R3	001 152 3152 8
R122	ERDS2TJ153	001 152 2351 7
R123	ERDS2TJ101	001 152 2421 0
R124	ERDS2TJ103	001 152 2347 3
R125	ERDS2TJ104	001 152 2348 2
R126	ERDS2TJ152	001 152 2350 8
R127	ERDS2TJ682	001 152 2365 1
R128	ERDS2TJ153	001 152 2351 7
R129	ERDS2TJ224	001 152 2433 6
R130	ERDS2TJ122	001 152 2423 8
R131, R132	ERDS2TJ333	001 152 2358 0
R133	ERDS2TJ102	001 152 2346 4
R134	ERDS2TJ392	001 152 2439 0
R135	ERDS2TJ102	001 152 2346 4
R136	ERDS2TJ182	001 152 2352 6
R137	ERDS2TJ681	001 152 2449 8
R138	ERDS2TJ333	001 152 2358 0
R139	ERDS2TJ222	001 152 2353 5
R140	ERDS2TJ223	001 152 2432 7
R141	ERDS2TJ153	001 152 2351 7
R142	ERDS2TJ821	001 152 2454 1
R143	ERDS2TJ474	001 152 2443 4
R144	ERDS2TJ471	001 152 2361 5
R145	ERDS2TJ270	001 152 2434 5
R171	ERDS2TJ154	001 152 2427 4
R172, R173	ERDS2TJ472	001 152 2362 4
R174	ERDS2TJ223	001 152 2432 7
R175	ERDS2TJ334	001 152 2438 1
R176	ERDS2TJ473	001 152 2363 3
R177	ERDS2TJ683	001 152 2450 5
R178	ERDS2TJ332	001 152 2357 1
R179	ERDS2TJ822	001 152 2455 0
R180, R181	ERDS2TJ682	001 152 2365 1
R182	ERDS2TJ822	001 152 2455 0
R183, R184	ERDS2TJ152	001 152 2350 8
R185	ERDS2TJ102	001 152 2346 4
R186, R187	ERDS2TJ182	001 152 2352 6
R188	ERDS2TJ102	001 152 2346 4
R189	ERDS2TJ471	001 152 2361 5
R190	ERDS2TJ120	001 152 3146 6
R301	ERDS2TJ682	001 152 2365 1
R302	ERDS2TJ104	001 152 2348 2
R303	ERDS2TJ334	001 152 2438 1
R304, R305	ERDS2TJ223	001 152 2432 7
R306	ERDS2TJ102	001 152 2346 4
R307	ERDS2TJ472	001 152 2362 4
R308	ERDS2TJ471	001 152 2361 5
R309	ERDS2TJ121	001 152 2349 1
R401, R402	ERDS2TJ472	001 152 2362 4
R403, R404	ERDS2TJ473	001 152 2363 3
R405	ERDS2TJ152	001 152 2350 8
R406, R407	ERDS2TJ103	001 152 2347 3
R408, R409	ERDS2TJ103	001 152 2347 3
R410, R411	ERDS2TJ472	001 152 2362 4
R412, R413	ERDS2TJ472	001 152 2362 4
R414, R415	ERDS2TJ472	001 152 2362 4
R416	ERDS2TJ223	001 152 2432 7
R417, R418	ERDS2TJ472	001 152 2362 4
R420	ERDS2TJ473	001 152 2363 3
R421	ERDS2TJ331	001 152 2356 2
R422	ERDS2TJ394	001 152 2441 6
R501, R502	ERJ8GEXK1R0	
R503	ERJ8GEYJ223	001 151 5630 6
R601, R602	ERDS2TJ222	001 152 2353 5
R603, R604	ERDS2TJ222	001 152 2353 5
R801, R802	ER0S2TKG1101	001 151 3323 2
R803, R804	ER0S2TKG1201	001 151 3324 1
R805, R806	ER0S2TKG33R0	001 151 4828 8
R807, R808	ER0S2TKG10R0	001 151 4827 9
R809, R810	ER0S2TKG1001	001 151 3320 5
R811, R812	ER0S2TKG3301	001 151 3338 5
R821, R822	ERDS2TJ391	001 152 2360 6
R823, R824	ERDS2TJ104	001 152 2348 2
R825, R826	ERDS2TJ222	001 152 2353 5
R827, R828	ERDS2TJ221	001 152 2431 8
R831	ERDS2TJ272	001 152 2354 4
R832	ERDS2TJ103	001 152 2347 3
R837, R838	ERDS2TJ104	001 152 2348 2
R845, R846	ERDS2TJ102	001 152 2346 4
R851, R852	ERDS2TJ103	001 152 2347 3
R853, R854	ERDS2TJ473	001 152 2363 3
R855, R856	ERDS2TJ820	001 152 2453 2
R857, R858	ERDS2TJ103	001 152 2347 3
CAPACITORS		
C1, C2 ⚠	ECKD1H223PF	001 103 1510 9
C3 ⚠	ECKD1H223PF	001 103 1510 9
C4, C5	ECEA1EU102	001 120 2705 9
C6, C7	ECEA1HU010	001 120 2842 1
C8 ⚠	ECKD1H223PF	001 103 1510 9
C11, C12	ECEA1CU222	001 120 3074 3
C13, C14	ECEA0JS221	001 120 2925 9
C15	ECEA1EU470	001 120 2841 2
C18	ECEA1HU470	001 120 3257 8
C19, C20	ECEA1CU470	001 120 2835 0
C21	ECFR1E104ZF	001 103 5089 5
C101	ECQM1H104JZ	001 106 0675 8
C102	ECEA1CU100	001 120 2905 3
C103	ECEA1HN2R2S	001 120 0356 8
C104	ECQM1H103JZ	001 106 0667 8
C105	ECQM1H224KVW	001 106 5164 6
C106	ECEA1CU100	001 120 2905 3
C107, C108	ECEA1HNR22BV	
C109	ECEA1HN2R2S	001 120 0356 8
C110	ECQM1H122JZ	001 106 0683 8
C111	ECQM1H473JZ	001 106 0810 9
C112	ECFR1E104ZF	001 103 5089 5
C113	ECQM1H153JZ	001 106 0704 0

Ref. No.	Part No.	Part Code
C114	ECEA1HN3R3S	001 120 0358 6
C115	ECFR1E104ZF	001 103 5089 5
C119	ECEA0JU101	001 120 2829 8
C120	RCBS1C103MYY	001 103 8060 6
C121	ECFR1E104ZF	001 103 5089 5
C122, C123	ECKD1H102KB	001 103 1414 8
C124	ECKD1H681K	001 103 1580 5
C127	ECCC1H220K	001 103 0493 7
C128	ECEA1HS0R1	001 120 3250 5
C129	ECEA1HU010	001 120 2842 1
C130	ECQV1H104JZ	001 106 2571 7
C131, C132	ECEA1HU100	001 120 3251 4
C133	ECEA1HNR33BV	
C134	ECKD1H182KB	001 103 1479.1
C135	ECKD1H682KB	001 103 1592 1
C136	ECQM1H333JZ	001 106 0779 1
C137	ECKD1H221KB	001 103 1487 1
C138	ECEA1HU010	001 120 2842 1
C139	ECEA1CN220BV	
C140	ECKD1H681K	001 103 1580 5
C141	ECFF1H103KR	
C142, C143	ECKD1H101KB	001 103 1412 0
C144	ECKR1H222KB	
C145	ECEA1AU220	001 120 3563 1
C146	ECEA0JU470	001 120 3125 9
C147, C148	ECKD1H102KB	001 103 1414 8
C149	ECQM1H153JZ	001 106 0704 0
C150	ECQM1H102JZ	001 106 0661 4
C151	ECQM1H153JZ	001 106 0704 0
C152, C153	ECQM1H104JZ	001 106 0675 8
C154	ECKD1H471KB	001 103 1551 0
C155	ECKD1H103PF	001 103 1449 7
C156	ECKD1H681K	001 103 1580 5
C301	ECEA1HN2R2S	001 120 0356 8
C302	ECFF1H103KR	
C303, C304	ECQM1H104JZ	001 106 0675 8
C305	ECCC1H220K	001 103 0493 7
C306	ECCD1H070CC	001 103 0271 9
C307	ECFR1E104ZF	001 103 5089 5
C308	ECKD1H471KB	001 103 1551 0
C309	ECQV1H104JZ	001 106 2571 7
C310	ECCD1H070CC	001 103 0271 9
C311, C312	ECCD1H470K	001 103 0627 1
C313, C314	ECCD1H470K	001 103 0627 1
C401	ECEA0JU470	001 120 3125 9
C402	ECFR1E104ZF	001 103 5089 5
C403	ECKD1H103PF	001 103 1449 7
C404	ECFD1H104ZF	001 108 0906 2
C405	ECQM1H103JZ	001 106 0667 8
C406	ECEA1HUR22	001 120 3247 0
C407	ECFD1H104ZF	001 108 0906 2
C408	ECKD1H102KB	001 103 1414 8
C501	ECEV1EV330	001 120 5624 7
C502	ECEV1HV010	001 120 5625 6
C504	GR426B273K25	001 103 7125 0
C506	GR426B152K50	001 120 5626 5
C507	GR426F104Z25	001 103 7127 8
C511, C512	ECEA1EN470S	001 120 2394 4
C513	ECEA1EN470S	001 120 2394 4
C601	RCBS1C103MYY	001 103 8060 6
C602	RCBS1H220JCY	001 103 5600 2
C803, C804	CQS2B391JCF	001 106 4821 0
C805, C806	ECQM1H103JZ	001 106 0667 8
C807, C808	RBP1CN220CT	001 120 5015 6
C809, C810	ECKD1H102KB	001 103 1414 8
C811, C812	ECEA0JU470	001 120 3125 9
C813, C814	REC1C221M0	
C815, C816	ECEA1CN220BV	
C818	ECKD1H471KB	001 103 1551 0
C851, C852	ECKD1H103PF	001 103 1449 7
C853, C854	ECKD1H332KB	001 103 1531 4
C857, C858	ECEA1CU100	001 120 2905 3
C859, C860	ECKD1H223PF	001 103 1510 9
C901 ⚠	ECKDKC103PF2	001 103 3734 7

• Terminal guide of IC's, transistors and diodes

AN6552F	8 Pin
SVIM5218P	
SVIM5238P	
AN6554	14 Pin
MN4053B	16 Pin
MN6030	22 Pin
SVIPCM54KP	28 Pin
MN15283PDP	64 Pin



MN1550PDM	18 Pin
MN4416S−12	24 Pin
AN8290S	
AN8370S	42 Pin



MN6618A	42 Pin
MN6617	84 Pin



SVIM51953BL



SVIBA6218

AN78M12, AN79M12
AN78M05



AN79N05



SVIFU15



EHDGA1243



SVIAL175



2SD973, 2SB793



2SA1309



UN4212, UN1231



SVDERA15, MA165



MA4082, MA4330
MA4056



SVDSLR−54MW4
LN66



MA154WA



MA154WK



■ REPLACEMENT PARTS LIST

Notes: * Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
* Bracketed indications in Ref. No. columns specify the area.
Parts without these indications can be used for all areas.
* "Ⓢ" mark parts are used for silver type only.
* "Ⓚ" mark parts are used for black type only.
Parts other than "Ⓢ" and "Ⓚ" marked are used for both silver and black types.

Ref. No.	Part No.	Part Code	Description
INTEGRATED CIRCUITS			
IC1	AN78M12	001 060 4333 2	I.C.
IC2	AN79M12	001 060 8254 4	I.C.
IC4, IC5	SVIFU15	001 060 8433 3	I.C.PROTECTOR
IC11	AN78M05	001 060 4137 4	I.C.
IC12	AN79N05	001 060 8714 7	I.C.
IC101	AN8370S	001 060 8399 8	I.C.
IC102, IC103	AN6554	001 060 4331 4	I.C.
IC106	MN4053B	001 060 7141 6	I.C.
IC301	MN6617	001 060 8411 9	I.C.
IC302	MN6618A	001 061 3043 8	I.C.
IC303	MN4416S-12	001 060 9746 5	I.C.
IC304	EHDGA1243	001 061 3036 7	I.C.
IC401	MN15283PDP		I.C.
IC402	SVIM51953BL	001 061 1423 8	I.C.
IC403	SVIBA6218	001 061 1421 0	I.C.
IC501	AN8290S	001 061 3034 9	I.C.
IC601	MN1550PDM	001 061 3230 7	I.C.
IC602 (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)	SVIHC-MD01E	001 061 3096 5	I.C.
IC602 (M, MC)	SVIHC-MD03M	001 061 3097 4	I.C.
IC801, IC802	SVIAL173		I.C.
IC803, IC804	SVIM5238P	001 060 9725 0	I.C.
IC805	SVILM833NA	001 060 4883 7	I.C.
IC806	AN6552F	001 060 0274 2	I.C.
IC807	SVIPCM54KP-1		I.C.
IC851	SVIM5218P	001 060 8796 9	I.C.
TRANSISTORS			
Q11	2SD973	001 030 1944 1	TRANSISTOR
Q12	2SB793-QRS	001 030 2766 7	TRANSISTOR
Q13	2SA1309	001 030 4058 0	TRANSISTOR
Q101	2SD973	001 030 1944 1	TRANSISTOR
Q102	2SB793-QRS	001 030 2766 7	TRANSISTOR
Q103	2SD973	001 030 1944 1	TRANSISTOR
Q104	2SB793-QRS	001 030 2766 7	TRANSISTOR
Q105	2SD973	001 030 1944 1	TRANSISTOR
Q106	2SB793-QRS	001 030 2766 7	TRANSISTOR
Q110	2SD637	001 030 1794 7	TRANSISTOR
Q408, Q409	UN4212	001 030 3019 1	TRANSISTOR
Q411, Q412	UN4212	001 030 3019 1	TRANSISTOR
Q413, Q415	UN4212	001 030 3019 1	TRANSISTOR
Q416	UN4212	001 030 3019 1	TRANSISTOR
Q801	2SA1309	001 030 4058 0	TRANSISTOR
DIODES			
D1, D2 ⚠	SVDERA15-04T	001 032 9312 5	RECTIFIER
D3, D4 ⚠	SVDERA15-04T	001 032 9312 5	RECTIFIER
D5, D6 ⚠	SVDERA15-04T	001 032 9312 5	RECTIFIER
D7, D8 ⚠	SVDERA15-04T	001 032 9312 5	RECTIFIER
D9 ⚠	SVDERA15-04T	001 032 9312 5	RECTIFIER
D11, D12	MA4082M	001 032 4955 6	DIODE
D13	MA4330L	001 032 7228 8	DIODE
D14	MA4082M	001 032 4955 6	DIODE
D101, D102	MA165	001 032 0494 0	DIODE
D103, D401	MA165	001 032 0494 0	DIODE
D417, D418	MA165	001 032 0494 0	DIODE
D501	MA153	001 032 0489 7	DIODE
D601, D602	MA165	001 032 0494 0	DIODE
D603, D604	MA165	001 032 0494 0	DIODE
D605, D606	MA165	001 032 0494 0	DIODE
D607, D608	MA165	001 032 0494 0	DIODE
D610, D611	MA165	001 032 0494 0	DIODE
D612, D613	MA165	001 032 0494 0	DIODE
D614, D615	MA165	001 032 0494 0	DIODE
D641, D642	SVDSLR-54MW4	001 032 8364 7	LED
D643	SVDSLR-54MW4	001 032 8364 7	LED
D801, D802	MA4056-M	001 032 7209 1	DIODE
D803	MA165	001 032 0494 0	DIODE
HALL ELEMENTS			
H501, H502	0H-001	001 036 0010 2	HALL ELEMENT
VARIABLE RESISTORS			
VR101	EVND3AA00B53	001 180 2644 9	5KΩ(B)
VR102, VR103	EVND3AA00B14	001 180 2642 1	10KΩ(B)
VR104, VR105	EVND3AA00B14	001 180 2642 1	10KΩ(B)
VR106	EVND3AA00B53	001 180 2644 9	5KΩ(B)
VR301	EVN38CA00B13	001 180 0549 5	1KΩ(B)
VR601	EVQWX3F2025B		200KΩ (B)
VR851	EVUN1AF15A15		100KΩ (A)
COILS AND TRANSFORMERS			
L301	ELEPH2R7MA		COIL
L501	NL4532T100K2	001 211 3218 9	COIL
L851, L852	ELEPG1R2MA	001 210 7215 1	COIL
T1 ⚠ (M, MC)	SLTD1133U	001 202 8568 1	POWER TRANSFORMER
T1 ⚠ (XL)	SLTD54JE49E		POWER TRANSFORMER
T1 ⚠ (EK, XA, XB) (PA, PE, PC)	SLTD54JE50E		POWER TRANSFORMER
T1 (E, EG, EB, EH) (EF, EI)	SLTD54JS48E1		POWER TRANSFORMER
OSCILLATORS			
X301	SVQ16CKSS	001 250 1471 7	16.9344MHZ
DISPLAYS			
FL601	SADD5		DISPLAY
FUSES			
F1 ⚠ (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)	XBA2C008TB0S		250V, T80mA
F2 ⚠ (EK, XA, XB) (PA, PE, PC)	XBA2C016TB0S	002 380 1470 5	250V, T160mA
SWITCHES			
S1 ⚠	ESB8249V	003 435 5877 0	POWER
S2 ⚠ (EK, XA, XB) (PA, PE, PC)	SRDSHXW0251	003 438 1067 7	VOLTAGE SELECTOR
S101	SSPD5	003 434 1032 8	REST
S601, S614	EVQQS405K	003 435 2832 5	OPERATION
S616, S619	EVQQS405K	003 435 2832 5	OPERATION
S622, S626	EVQQS405K	003 435 2832 5	OPERATION
S628	EVQQS405K	003 435 2832 5	OPERATION
RELAYS			
RL801	SSYD3		RELAY

Ref. No.		Part No.	Part Code	Description
CABINET AND CHASSIS				
1	Ⓚ	SKCLP520-KM	016 800 2982 4	TOP COVER ASS'Y
1	Ⓢ	SKCLP520-SE	016 800 2984 2	TOP COVER ASS'Y
2	Ⓚ	SGWLP520-KM	016 840 7366 8	FRONT PANEL ASS'Y
2	Ⓢ	SGWLP520-SE		FRONT PANEL ASS'Y
8	Ⓢ	SBN1161	016 700 0471 7	KNOB
8	Ⓚ	SBN1161-2	016 700 1849 9	KNOB
9	Ⓚ	SGYLP520-KM		FRAME ASS'Y
9	Ⓢ	SGYLP520-SE	016 840 7401 2	FRAME ASS'Y
9-1		SGUD149A	016 842 1552 2	PANEL
9-2		SDUD16A	016 842 1553 1	FILTER
9-3	Ⓢ	SGXD2301MA	016 846 3669 2	COVER, BUTTON
9-3	Ⓚ	SGXD2301ZC	016 846 3668 3	COVER, BUTTON
9-4	Ⓢ	SBCD3841MA0A	016 702 6893 5	BUTTON
9-4	Ⓚ	SBCD3841ZC0A	016 702 6892 6	BUTTON
10		SDUD17	016 862 1073 0	PANEL
12	Ⓢ	SBCD3861MA	016 702 6890 8	BUTTON
12	Ⓚ	SBCD3861ZC	016 702 6891 7	BUTTON
13		SUSD57	016 726 0906 9	SPRING
14	Ⓢ	SBCD3810MA1	016 702 6889 1	BUTTON
14	Ⓚ	SBCD3810ZK1	016 702 6883 7	BUTTON
16	Ⓢ	SBND50MA	016 700 1946 9	KNOB
16	Ⓚ	SBND50ZC	016 700 1947 8	KNOB
16-1		SHR9451	016 652 0151 7	SPACER
17 (XL)	⚠	SJSD16	003 400 7436 6	AC SOCKET
17 (M, MC, E, EK) (EG, EB, EH) (EF, EI, XA) (XB, PA, PE) (PC)	⚠	SJS9236	003 403 4660 7	AC SOCKET
18	Ⓢ	SBC666	016 702 5545 6	BUTTON
18	Ⓚ	SBC666-5	016 702 6679 9	BUTTON
19		SUBD3-2	016 712 0346 5	ROD
20		SHGD95-1	016 653 1136 7	CUSHION RUBBER
23		SUSD65	016 726 0903 2	SPRING (YELLOW)
24		SUSD42	016 726 0841 9	SPRING (SILVER)
25		SUSD66	016 726 0904 1	SPRING (WITH BLUE MARK)
27		SKLD5	016 828 0321 1	INSULATOR
29 (M)		SGPD611KY0A		CHASSIS
29 (XA)		SGPD611KY1A		CHASSIS
29 (E)		SGPLP520-KE	016 840 7346 2	CHASSIS
29 (EB, EH.EF) (EI)		SGPLP520-KEB	016 840 7341 7	CHASSIS
29 (EG)		SGPLP520-KEG	016 840 7343 5	CHASSIS
29 (EK)		SGPLP520-KEK	016 840 7345 3	CHASSIS
29 (PA, PE, PC)		SGPLP520-KPA	016 840 7342 6	CHASSIS
29 (XB)		SGPLP520-KXB	016 840 7355 1	CHASSIS
29 (XL)		SGPLP520-KXL	016 840 7344 4	CHASSIS
29 (MC)		SGPLP720-KMC		CHASSIS
31		SJFD4	003 410 7707 6	TERMINAL PLATE
34		SJJ134B	003 400 7050 0	JACK, HEADPHONES
CONNECTORS				
41, 42		SJSD0905	003 403 4153 1	CONNECTOR (CN405, 404)
43, 44		SJSD0905	003 403 4153 1	CONNECTOR (CN403, 402)
45		SJSD0905	003 403 4153 1	CONNECTOR (CN401)
46		SJSD1709	003 403 6503 1	CONNECTOR (CN101)
47		EMCS0350Z	003 402 1227 7	CONNECTOR (CN104)
48		EMCS0850Z		CONNECTOR (CN1)
49		EMCS0550Z	003 402 1233 9	CONNECTOR (CN801)
50		SJTD713-R		CONNECTOR (CN302)
51		SRDJ001N14E	003 410 6157 8	SHORTING PIN (CN102)
52		EMCS0550Z	003 402 1233 9	CONNECTOR (CN407)
53		EMCS0552M	003 402 0112 1	CONNECTOR (CN102)
SCREWS, WASHERS AND NUTS				
N1		XTV3+8JFZ	005 501 0919 2	SCREW
N2		SHDD1-3		SCREW
N3		XTV3+8JFN	005 501 1326 7	SCREW
N4		XTV3+8J	005 501 0901 2	SCREW
N5	Ⓢ	SRXG007N10	005 500 5434 3	SCREW
N5	Ⓚ	SRXG007N51	005 500 5012 1	SCREW
N6		XTBS3+8JFZ1	005 501 2523 0	SCREW
N11		SNE4021	005 507 0372 5	NUT
N12		SHDD1-4	016 652 0709 1	SCREW
N13 (EK, XA, XB) (PA, PE, PC)		XTV3+8JFZ	005 501 0919 2	SCREW

Ref. No.		Part No.	Part Code	Description
LOADING MECHANICAL				
1		SIRLP720-KM	016 652 0715 3	TRAY ASS'Y
1-1		SHSD14	016 643 1002 6	SHEET
1-2		SHGD49	016 653 1079 9	RUBBER
3		SHGD92	016 653 1143 8	RUBBER
4	Ⓢ	SGXD240MA0C	016 846 3662 9	ORNAMENT
4	Ⓚ	SGXD240ZK0B	016 846 3661 0	ORNAMENT
5		SUSD29-1	016 726 0845 5	SPRING
6		SIRD20-1	016 718 3365 0	LEVER
7		SIRD16E-1	016 631 0043 7	HOLDER ASS'Y
7-1		SHGD46	016 653 1080 6	RUBBER
9		SUWD46	016 650 5256 9	BRACKET
10		SUXD25	016 634 0124 2	SHAFT
11	⚠	S0ALP1200-KM	001 271 0692 3	OPTICAL PICKUP ASS'Y
12		EWSL04A00000	016 631 0044 6	HOLDER
13		SHGD47	016 653 1070 8	SPACER
14		S0RD10E	001 211 3219 8	COIL
15		EWS7B0A00Q53	001 174 8773 3	RESISTANCE UNIT
16		S0YD8E	016 634 0128 8	YOKE
17		S0YD9	016 634 0125 1	YOKE
18		SJGD4E	002 310 2308 2	MOTOR ASS'Y
19		SHGD64	016 653 1072 6	RUBBER
21		SDRD2	016 740 0117 8	PULLEY
22		SUWD44	016 650 5250 5	BRACKET
23		SHGD69	016 653 1078 0	RUBBER
26		SIRD17-1E	016 652 0711 7	CLAMPER
27		SIRD28-1	016 652 0712 6	HOLDER
28		SDGD19	016 745 0199 5	GEAR
29		SDGD20-1	016 745 0202 7	GEAR
31		SD0D8	005 512 0399 3	RING
32		SRQA010N04	017 726 0412 8	SPRING
33		SD0D7-1	016 766 0190 7	TURNTABLE ASS'Y
34		SISD7E-2	016 630 1787 5	BASE
39		SMBD2-1	016 754 0059 5	BELT
40		SHRD23	016 652 0633 4	LOCK SHAFT
41		S0MA9A	016 743 0060 3	ROTOR ASS'Y
42		SXPD830	003 483 1207 8	SPINDLE P.C.B
43		SHRD19-1	016 652 0710 8	LEVER
44		SUSD31	016 726 0843 7	SPRING
45		SUSD51	016 726 0846 4	SPRING
47		SUSD67-1	016 726 0911 2	SPRING
48		SUWD58	016 650 5322 6	PLATE
49		SUSD68	016 726 0910 3	SPRING
50		SGXD260ZK	016 846 3621 8	PLATE
SCREWS,WASHERS AND NUTS				
N1		SNSD10	005 500 5675 8	SCREW
N2		XTN2+4G	005 501 2780 5	SCREW
N3		XQN17+A6	005 500 4900 2	SCREW
N5		XTW3+8T	005 501 1358 9	SCREW
N6		XXE26D5	005 500 5095 2	SCREW
N7		SNSD9	016 726 0765 4	SCREW
N8		XSN26+6	005 500 1364 6	SCREW
N9		SFXW120-01	005 513 0957 0	WASHER
N10		XSN26+8	005 500 1368 2	SCREW
N11		XTN2+5G	005 501 3534 3	SCREW
N12		XTV3+6BFN	005 501 0888 2	SCREW
N13		XTV3+6GFZ	005 501 3160 3	SCREW
N14		XTV3+8G	005 501 0913 8	SCREW
N15		SFXGQ06N01	005 500 4983 3	SCREW
N18		XTV3+14G	005 501 0851 5	SCREW

Ref. No.		Part No.	Part Code	Description
INTEGRATED CIRCUITS				
IC1 (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)		MN6030B	001 060 6133 0	I.C.
IC1 (M, MC)		MN6030CA	001 060 8758 5	I.C.
TRANSISTORS				
Q1		UN1231	001 030 5092 4	TRANSISTOR
DIODES				
D1		LN66-S	001 032 3730 5	LED
D2, D3		MA154WK	001 032 3491 1	DIODE
D4, D5		MA154WK	001 032 3491 1	DIODE
D6, D7		MA154WA	001 032 3490 2	DIODE
OSCILLATOR				
X1 (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)		CSB420PB1	001 030 0013 9	420 KHZ
X1 (M, MC)		CSB455EB1T	001 250 1475 3	455 KHZ
RESISTORS				
R1		ERDS2TJ1R0	001 152 2419 4	CARBON, 1/4W, 1Ω
CAPACITORS				
C1 (M, MC)		ECKD1H101KB	001 103 1412 0	CERAMIC, 50V, 100PF
C1		ECKD1H471KB	001 103 1551 0	CERAMIC, 50V, 470PF
(E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)				
C2		ECKD1H101KB	001 103 1412 0	CERAMIC, 50V, 100PF
(M, MC)				
C2 (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)		ECKD1H121KB	001 103 1455 9	CERAMIC, 50V, 120PF
C3		ECEA0JK101	001 120 0136 8	ELECTROLYTIC, 6.3V, 100μF
REMOTE CONTROL TRANSMITTER				
1		UR64PP124C	016 840 6377 9	PANEL
2	Ⓚ	UR64CS119	016 640 0420 1	TOP COVER
2	Ⓢ	UR64CS119A	016 640 0436 3	TOP COVER
3		UR64SB125	016 861 2468 6	PLATE
4		UR64BT123A	016 702 6323 4	BUTTON
5		UR64CT122	016 653 1011 9	RUBBER, SWITCH
6	Ⓚ	UR64CS120	016 640 0419 4	BOTTOM COVER
6	Ⓢ	UR64CS120A	016 802 1864 3	BOTTOM COVER
7		UR64LB126AF	016 862 1000 7	LABEL
8	Ⓚ	UR64EC121	016 802 1716 4	COVER, BATTERY
8	Ⓢ	UR64EC121A	016 820 0513 5	COVER, BATTERY
9		UR64TD128	003 413 1408 3	TERMINAL ⊖
10		UR64TD127	003 413 1407 4	TERMINAL ⊕
11		UR52TD101	003 413 1406 5	TERMINAL
SCREWS,WASHERS AND NUTS				
N1	Ⓢ	XTS26+12GFC	005 501 3171 0	SCREW
N1	Ⓚ	XTS26+12GFZ	005 501 3122 9	SCREW

Ref. No.		Part No.	Part Code	Description
PACKINGS				
P1 (M, E, EK, XL) (EG, EB, EH) (EI, XA, XB) (PA, PE, PC)	Ⓚ	SPND115	016 971 4845 0	CARTON BOX
P1 (MC)	Ⓚ	SPND116		CARTON BOX
P1 (EF)	Ⓚ	SPND117		CARTON BOX
P1 (EF)	Ⓢ	SPND120		CARTON BOX
P1 (E, EK, XL, EG) (EB, EH, EI) (XA, XB, PA) (PE, PC)	Ⓢ	SPND121		CARTON BOX
P2		SPSD69	016 971 4849 6	PAD
P3		SPSD70	016 971 4850 3	PAD
P4		SFYH60X50	016 978 0479 3	PROTECTION COVER
P5		SPSD68	016 977 3081 4	SHEET
P6		SRHZJ02N01	017 978 0097 5	PROTECTION COVER
P7		XZB23X20C03	016 978 0480 0	POLYETHYLENE BAG
P9		SFYF09A21	017 978 0083 1	POLYETHYLENE BAG
ACCESSORIES				
A1 (E, EB, EH)		SQXLP520-KE	016 983 4964 8	INSTRUCTION BOOK
A1 (MC)		SQXLP520-KMC	016 983 4965 7	INSTRUCTION BOOK
A1 (PA, PE, PC)		SQXLP520-KPA	016 983 4963 9	INSTRUCTION BOOK
A1 (XB)		SQXLP520-KXB	016 983 4962 0	INSTRUCTION BOOK
A1		SQX54099	016 983 4966 6	INSTRUCTION BOOK
(M) A1 (XL, EF, XA)		SQX54101	016 983 4953 1	INSTRUCTION BOOK
A1 (EK)		SQX54103-1	016 989 0754 2	INSTRUCTION BOOK
A1 (EG)		SQX54104	016 983 4968 4	INSTRUCTION BOOK
A1 (EI)		SQX54105	016 983 4967 5	INSTRUCTION BOOK
A2 (EK)	⚠	SFDAC05G02	003 490 2613 3	AC CORD
A2 (PA, PE, PC)	⚠	SJA168	003 490 4122 9	AC CORD
A2 (M)	⚠	SJA170-1	003 490 5022 8	AC CORD
A2 (E, EG, EB, EH) (EF, EI, XA)	⚠	SJA171	003 490 4160 3	AC CORD
A2 (XL)	⚠	SJA173	003 490 4161 2	AC CORD
A2 (XB)	⚠	SJA183	003 490 4873 7	AC CORD
A3		SJP2249-1	003 492 6446 4	OUTPUT CORD
A4 (XB, PA, PE) (PC) ONLY	⚠	RJP120ZBS-H	003 402 1437 9	PLUG
A5 (XA)	⚠	SFDK-119118	003 402 0523 6	PLUG
A6 (E, EK, XL, EG) (EB, EH, EF) (EI, XA, XB) (PA, PE, PC)		UM-3NE		BATTERY
A6 (M, MC)		UM-3NEP		BATTERY

■ EXPLODED VIEW

1 2 3 4 5 6 7 8 9 10

A B C D E F

• Remote control parts



• Cabinet and chassis parts















Note: When ch
apply th
marked '

• Cabinet and chassis parts



• Loading unit



Note: When changing mechanism parts, apply the specified grease to the areas marked "× ×" shown in the drawing.

■ PRINTED CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM



■ PRINTED CIRC

E POWER SUP

• For U.

• For Co

• For Ot

DIAGRAM



■ PRINTED CIRCUIT BOARDS

E POWER SUPPLY P.C.B.

- **For U.S.A. and Canada**



- **For Continental Europe and Australia**



- **For Others**



B MAIN P.C.B.



A OPERATION P.C.B.



C SPINDLE MOTOR DRIVE P.C.B.



REMOTE CONTROL P.C.B.





A OPERATION P.C.B.



C SPINDLE MOTOR DRIVE P.C.B.



D HEADPHONES AMP P.C.B.



REMOTE CONTROL P.C.B.



■ SCHEMATIC DIAGRAM

(This schematic diagram may be modified at any time with the development of new technology.)

Notes:

1. **S1** : Power switch in "**on**" position.
2. **S2** : Voltage selector switch. (For [EK], [XA], [XB], [PA], [PE] and [PC] areas.)
3. **S101** : Disc holder open/close detection switch.
4. **S601~610** : Numeric switch.
5. **S611** : Index switch.
6. **S612** : Auto space switch.
7. **S613** : Clear switch.
8. **S614** : Memory switch.
9. **S616** : A-B repeat switch.
10. **S617** : Forward skip switch.
11. **S618** : Backward skip switch.
12. **S619** : Time mode switch.
13. **S622** : Pause switch.
14. **S623** : Repeat switch.
15. **S624** : Play switch.
16. **S625** : Stop switch.
17. **S626** : Open/close switch.
18. **S628** : Search dial on/off switch.
19. The voltage value and waveform are the reference voltage of this unit measured by DC electronic voltmeter (high impedance) and oscilloscope on the basis of chassis.

Accordingly, there may arise some error in voltage values and waveforms depending upon the internal impedance of the tester or the measuring unit.

* The parenthesized are the values of voltage generated during playing (Test disc 1kHz, L+R, 0dB), others are voltage values in stop mode.

20. Important safety notice:
Components identified by ⚠ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.
21. ——— : Positive voltage lines and negative voltage lines.
▒▒▒ : Audio signal lines.

* Caution!

IC and LSI are aensitive to static electricity. Secondary trouble can be prevented by taking care during repair.

* Cover the parts boxes made of plastics with aluminum foil.
* Ground the soldering iron.
* Put a conductive mat on the work table.
* Do not touch the legs of IC or LSI with the fingers directly.

■ INTERNAL CONNECTIONS OF FL

• Grid connection diagram



• Anode connection table

	15G	14G	13G	12G	11G	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
a	1	2	3	4	5	a	a	a	a	a	a	a	a	↺	0dB
b	6	7	8	9	10	b	b	b	b	b	b	b	b	P	2dB
c	11	12	13	14	15	c	c	c	c	c	c	c	c	A↺	4dB
d	16	17	18	19	20	d	d	d	d	d	d	d	d	B	6dB
e	1	2	3	4	5	e	e	e	e	e	e	e	e	M.scan	8dB
f	6	7	8	9	10	f	f	f	f	f	f	f	f	A.space	10dB
g	11	12	13	14	15	g	g	g	g	g	g	g	g	F	12dB
h	16	17	18	19	20	▶	track	-	index	❚❚	min	col	sec	S	-
i	-	-	-	-	-	>	disc	-	No.	—	A Pause	-	▶	-	-

• Remote control unit



• Remote control data code





Button	Data Code
1	0 0 0 0 1 0
2	1 0 0 0 1 0
3	0 1 0 0 1 0
4	1 1 0 0 1 0
5	0 0 1 0 1 0
6	1 0 1 0 1 0
7	0 1 1 0 1 0
8	1 1 1 0 1 0
9	0 0 0 1 1 0
0	1 0 0 1 1 0
memory	0 1 0 1 0 1
index	0 0 0 1 0 1
time	1 0 0 1 0 1
stop	0 0 0 0 0 0

Button	Data Code
clear	1 1 0 1 0 0
A-B repeat	0 0 0 1 0 0
repeat	1 1 1 0 0 0
M scan	1 1 1 1 0 0
recall	1 0 0 1 0 0
◀◀ search	0 0 1 0 0 0
search ▶▶	1 0 1 0 0 0
▮◀ skip	0 1 0 0 0 0
skip ▶▮	1 1 0 0 0 0
❚❚ pause	0 1 1 0 0 0
play ▶	0 1 0 1 0 0
▼ level	1 0 1 0 0 1
level ▲	0 0 1 0 0 1



• Power supply circui (For Continental Eu



• Remote control unit



• Remote control data code



*1T = 0.420ms~0.424ms (U.S.A. and Canada)
1T = 0.454ms~0.460ms (Europe and Others)



Button	Data Code
1	0 0 0 0 1 0
2	1 0 0 0 1 0
3	0 1 0 0 1 0
4	1 1 0 0 1 0
5	0 0 1 0 1 0
6	1 0 1 0 1 0
7	0 1 1 0 1 0
8	1 1 1 0 1 0
9	0 0 0 1 1 0
0	1 0 0 1 1 0
memory	0 1 0 1 0 1
index	0 0 0 1 0 1
time	1 0 0 1 0 1
stop	0 0 0 0 0 0

Button	Data Code
clear	1 1 0 1 0 0
A-B repeat	0 0 0 1 0 0
repeat	1 1 1 0 0 0
M scan	1 1 1 1 0 0
recall	1 0 0 1 0 0
◀◀ search	0 0 1 0 0 0
search ▶▶	1 0 1 0 0 0
⏮ skip	0 1 0 0 0 0
skip ⏭	1 1 0 0 0 0
⏸ pause	0 1 1 0 0 0
play ▶	0 1 0 1 0 0
▼ level	1 0 1 0 0 1
level ▲	0 0 1 0 0 1



• Power supply circuit (For Continental Europe and Australia)



• Power supply circuit (For others)



LOADING MOTOR
IC403 SVIBA6218
IC106 BU4053B or MN4053B
OPTICAL PICKUP
LOADING MOTOR DRIVE
FL DRIVE
SYSTEM CONTROL
RESET SIGNAL GENERATOR
FOCUS, TRACKING and SERVO
OPTICAL SERVO
SPINDLE MOTOR DRIVE
IC401 MN15283PDP
IC402 SVIM5I953BL
IC101 AN8370S
IC102 SVIM5228P or AN6554
IC501 AN8290S
Q101,103,105 2SD1227M or 2SD973
Q102,104,106 2SB911M or 2SB793
Q110 2SC2021M or 2SD637
Q408,409,411~413 415,416 DTC124ESTor UN4212
Best eye adj.
Tracking error compe
Tracking offset adj.
Focus gain adj.
Focus offset adj.
Tracking gain
FC605
FC604
FC603
FC602
FC601
B MAIN CIRCUIT
C

OPTICAL PICKUP

FOC TRK A1 A3 A4 A2 GND RF Vcc

FOCUS, TRACKING and SERVO

Play 2ms 5V/DIV
Play 2ms 0.2V/DIV
Play 2ms 0.8
Play 2ms 0.2V/DIV
Play 2ms 0.1V/DIV
Play 2ms 0.3
Best eye adj.
CN102
Tracking error compensation adj.
Tracking offset adj.
Focus gain adj.
Focus offset adj.
Tracking gain adj.
Play 0.5µs 0.1V/DIV
Play 2ms 0.5V/DIV
Play 2ms 0.5V/DIV
Play 0.5µs 1V/DIV
Play 0.14ms
Play 13.5ms
Play 0.1ms 1V/DIV
Play 5ms 1V/DIV
0.23µs
Play 25ms
22.7µs
Play 0.23µs
Play 138µs
Play 2µs 1V/DIV
Play 0.5ms 1V/DIV
Play 2µs 1V/DIV
16.9344MHz
11.35µs
Play 5ms 1V/DIV
Play 1ms
Play 0.5ms 1V/DIV
Play 5µs 1V/DIV
Play 1kHz
Play 1kHz 0dB

IC101 AN8370S
IC102 SVIM5228Por AN6554
IC103 SVIM5228Por AN6554
IC104 DATA SLICE AND PLL
IC301 MN6617
IC302 MN6618A
IC303 SVICXK5816 or MN4416S-12
IC304 EHDGAI243
IC807 SVIPCM54JP-V
X301 SVQ16CKSS 16.9344MHz

Q101 Q102,104,106 2SB911M or 2SB793
Q103 Q105 Q106 2SB911M or 2SB793
Q110 2SC202IM or 2SD637
Q11 2SD1227M or 2SD973
Q12 2SB911M or 2SB793
Q13 2SA1309

DIGITAL SIGNAL PROCESSING

DIGITAL FILTER

D/A CONVERTER

16K RAM

OPTICAL SERVO

SPINDLE MOTOR DRIVE C

IC501 AN8290S
H501, 502 OH-011


REGULATOR
IC1 AN78MI2
IC2 AN79MI2
RECTIFIER
D1~4 SVDERAI5-04
D5~8 SVDERAI5-04
IC4,5 SVIFUI5
IC11 AN78M05
IC12 AN79N05
Q11 2SDI227M or 2SD973
Q12 2SB911M or 2SB793
Q13 2SAI309
E POWER SUPPLY
• For U.S.A and Canada.
AC 120V (60Hz)
D HEADPHONES AMP.
IC851 SVIM5218P
HEADPHONES
IC301 MN6617
DIGITAL SIGNAL PROCESSING
IC302 MN6618A
DIGITAL FILTER
IC303 SVICXK5816 or MN4416S-12
16K RAM
IC304 DATA SLICE AND PLL
IC304 EHDGAI243
X301 SVQ16CKSS 16.9344MHz
PLL adj.
IC807 SVIPCM54JP-V
D/A CONVERTER
IC801 SVIAF822 FILTER
IC804 SVIM5238P
CLASS-AA SAMPLE HOLD
IC803 SVIM5238P
IC805 SVILM833
BUFFER AMP.
IC806 SVIM5218P or SVIBA4558 or AN6552
IC802 SVIAF822
FILTER
RELAY DRIVE
Q801 2SAI309
D803 MAI65
OUTPUT
L ch
R ch
JK801
JK851 HEADPHONES
CN1
BT1
BT851
CN801
S1 POWER

■ BLOCK DIAGRAM




Search dial
IC401
SYSTEM CONTROL, and FL DRIVE
KEY MATRIX
FL
SMCK
RST
BLKCK
SUBQ
CLDCK
FLOCK
SENSE
CNT4
CNT3
CNT2
CNT1
MUTE
MDATA
MCLK
MLD
STAT
Motor drive
Selector
IC403
Loading motor
IC103
Speed/. Position detector
Resistans unit
IC106
Switch
IC103
Traverse servo
IC103 Q101,102
Traverse coil drive
Traverse coil
TRAVERSE SERVO
IC402
REMOTE CONTROL DATA PROCESSING
IC602
Remote control receiver
3V
Q1
LED drive
Modulation
Pulse generator
11 bit lach
Chattering simuldepression inhibit
Timing generation circuit
Key input control circuit
IC1
Key switch
REMOTE CONTROL TRANSMITTER
16K RAM
IC303
Row decoder
Memory array
Data control
Column I/O
Column decoder
Chip select, write enable, output enable
E.F.M. DECODER ERROR CORRECTION and CLV SERVO
IC302
FPC
EFM
PCK
CLDCK
BLKCK
SUBQ
EMPHA
SRF
PC
EC
Synchronize det
Frequency detector
Synchronize protection
EFM decoder
PCK timing
Sub-code decoder
Syn-drome
CCU
Working RAM
ALU
Compen-sation
Address generator
Rough servo
Severe servo
Processing
CLV control
MCK timing
Track counter
CPU interface
Address
WE
OE
+B
RST
DO
TRON
X301
16.9344MHz
OSC
SMCK
RDC
DIGITAL FILTER
Input resistor
RAM1 address counter
RAM2 address counter
RAM1
RAM2
Logic
Logic
Acqum-lator
ROM
Timing generator
Over flow limitter
Output resistor
CPU interface
IC807
D/A converter
FL601
AC 4.5V
Q13
Regulator
D9
Rectifier
-32V
12V
-12V
11.5V
5V
7.6V
-7.6V
-5V
-11.5V
IC1
IC2
IC11
IC12
Q11
Q12
IC4
IC5
IC protector
D1~4
D5~8
T1
Power transformer
AC IN
S1 POWER
RLY801
Relay drive
Relay
IC803
CLASS-AA sample hold
IC801
IC802
LPF
IC805
IC806
Buffer
IC851
Head phones amp
L ch
R ch
Head phones

Search dial

IC401

SYSTEM CONTROL, and FL DRIVE

SMCK 64
RST 13
BLKCK 14
SUBQ 20
CLDCK 19
Motor drive
Selector
IC403
Loading motor
MUTE
MDATA
MCLK
MLD
STAT
FLOCK
SENSE
CNT4
CNT3
CNT2
CNT1

KEY MATRIX

F L

IC402

REMOTE CONTROL
DATA PROCESSING

SMCK 2
RST 5

IC602
Remote control receiver

IC103
Speed/. Position detector
Resistans unit

IC106
Switch

IC103
Traverse servo

IC103 Q101,102
Traverse coil drive

Traverse coil

TRAVERSE SERVO

3V
Q1
LED drive
Modulation
Pulse generator
11 bit lach
Chattering simuldepression inhibit
Timing generation circuit
Key input control circuit
IC1
Key switch

REMOTE CONTROL TRANSMITTER

FL601
AC 4.5V
Q13
Regulator
D9
Rectifier
−32V
12V
−12V
11.5V
5V
7.6V
−7.6V
−5V
−11.5V
IC1
Regulator
IC2
Regulator
IC11
Regulator
Q11
Regulator
IC4
IC protector
Q12
Regulator
IC5
IC protector
IC12
Regulator
T1
Power transformer
D1~4
Rectifier
D5~8
Rectifier
AC IN
S1
POWER

16K RAM

IC303
Row decoder
Memory array
Data control
Column I/O
Column decoder
Chip select, write enable, output enable

E.F.M. DECODER ERROR CORRECTION and CLV SERVO

IC302
FPC
EFM
PCK
CLDCK
BLKCK
SUBQ
EMPHA
SRF
PC
EC
Synchronize det
Synchronize protection
PCK timing
Frequency detector
EFM decoder
Sub-code decoder
Syn-drome
CCU
Working RAM
ALU
Compen-sation
Address generator
Rough servo
Severe servo
Processing
CLV control
MCK timing
Track counter
CPU interface
(MUTE) Address
WE
OE
+B
RST
DO
TRON
X301
16.9344MHz
OSC
SMCK
RDG
STAT
MDATA
MCLK
MLD

DIGITAL FILTER

IC302
Input resistor
RAM1 address counter
RAM2 address counter
RAM1
RAM2
Logic
Logic
Acqum-lator
ROM
Over flow limitter
Output resistor
Timing generator
CPU interface

IC807
D/A converter

Relay drive
RLY801
Relay

IC803
CLASS-AA sample hold
IC805
Buffer
IC801
LPF
IC802
LPF
IC806
Buffer
IC851
Head phones amp
L ch
R ch
Head phones

F L

IC402

REMOTE CONTROL
DATA PROCESSING

14
17
7
10
13

IC602
Remote control receiver

3V
Q1
LED drive
6
Modulation
Pulse generator
11 bit lach
Chattering simuldepression inhibit
1,2,3
22
3V
Timing generation circuit
Key input control circuit
IC1
8
13
4
5
14
21
Key switch

REMOTE CONTROL TRANSMITTER

FL601
AC 4.5V
Q13
Regulator
D9
Rectifier
T1
Power transformer
AC IN
S1
POWER
−32V
12V
−12V
11.5V
IC1
Regulator
Regulator
IC2
D1~4
Rectifier
IC11
Regulator
5V
Q11
Regulator
7.6V
IC4
IC protector
Q12
Regulator
IC5
IC protector
D5~8
Rectifier
−7.6V
IC12
Regulator
−5V
−11.5V

Relay drive
RLY801
Relay

02
Output resistor
2
4
6
8
10
12
15
18
20
39
40
42
36
37
34
28

IC807
D/A converter
2
3
5
18
20

IC803
CLASS-AA sample hold
15
11
19
17
IC801
18
10
5
7
LPF
IC805
Buffer
3
L ch
IC806
Buffer
IC851
Head phones amp
IC806
Buffer
IC851
Head phones amp
Head phones
IC803
CLASS-AA sample hold
IC802
LPF
IC805
Buffer
R ch

■ PACKING



Printed in Japan
861008000 Ⓗ SM/HS